



HOMMER
HOME APPLIANCES

Electric Oven



En

User Manual

READ AND SAVE THESE INSTRUCTIONS

Attention: Pictures in the IM are for reference only.

011.031.055

220-240V, 50-60Hz, 2400W.



NAME OF PARTS:



- a. Time control knob
- b. Bottom temperature control knob
- c. Heaters and function control knob
- d. Upper temperature control knob
- e. Housing
- f. Door handle
- g. Glass door
- h. Bake tray
- i. Wire rack
- j. Tray handle

CONTROL PANEL AND OPERATING AND INSTRUCTIONS



Upper and bottom Temperature settings :

The adjustable temperature range from 70 °C to 250 °C

After the oven temperature reaches a predetermined degree, the thermostat automatically enter state

Function settings:



The upper heating element is working



The lower heating element is working



both upper and lower heating elements are working



Convection function is working together both upper and lower heating elements

Timer:

From 0-120 minutes adjustable

Note: the printed pattern on the product control panel may be changed without any notice.

IMPORTANT SAFEGUARD

When using this oven cooker, basic precautions should always be followed, including the following:

1. Read all instructions.
2. Be sure the socket is well earthed before you plug this appliance.
3. Do not touch hot surfaces of the hot plates and oven, Use handles or knobs.
4. Close supervision is necessary when it is used by or near children.
5. To protect against electric shock, do not immerse cord, plug, or any parts of the oven cooker into water or other liquid.
6. Do not let cord hang over edge of table or counter or touch hot surfaces.
7. Do not operate appliances with damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return it to the nearest Authorized Service Center for examination, repair, or adjustment.
8. The use of accessory attachments not recommended may cause hazard or injury.
9. Do not place on or near a hot gas or electric burner, or in a heated oven or in a microwave oven.
10. When operating the oven keep at least four inches of space on all sides of the oven to allow for adequate air circulation.
11. Unplug from outlet when not in use and before cleaning. Allow cooling before putting on or taking off parts, and before cleaning.
12. To disconnect, turn the control to OFF, then remove the plug, always hold the plug, but never pull the cord.
13. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
14. Do not cover any part of the oven with metal foil.
15. Do not clean with metal scouring pads pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
16. Never leave the appliance unattended while broiling or toasting.
17. Oversized foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
18. A fire may cause if the oven is covered or touching inflammable material, including curtains draperies, walls. And like, when on operation. Do not store any item on the oven during operation.

19. Extreme caution should be exercised when using containers constructed of anything other than metal or glass.
20. Do not place any of the following materials in the oven: cardboard, plastic, paper, or anything similar.
21. Do not store any materials, other than recommended accessories in this oven when operating.
22. Always wear protective, insulated oven gloves when inserting or removing items from the hot oven.
23. Do not use outdoors.
24. Do not use appliance for other than intended use.

BEFORE USING YOUR OVEN COOKER

Before using this oven cooker for the first time

1. Make sure that the oven is unplugged, and the TIMER switch is in the "OFF" position
2. Remove all rack and pans and clean them in hot sudsy water or in the dishwasher.
3. Thoroughly dry all accessories and re-assemble in oven. Plug oven into socket and you are ready to use your new oven.
4. After re-assembling your oven, we recommend that you run it at the MAX temperature, turn on all the function of oven and hot plates for approximately 15 minutes to eliminate any packing oil that may remain after shipping.

FOR OVEN

Do not worry about the smoke for the first operating, as it is normally for the first heating, and will disappear within 20 mins. In general, it is not necessary to preheat the oven, as the unit had the trial-run in the production line. But you may better result if you heat the oven before cooking some delicate meals, such as rare medium meat and cakes.

HOW TO BAKE

1. Place the removable rack into the desired position.

2. Place the bake pan on the wire rack. Shut the oven door.
3. Turn the timer dial to the desired cooking time.
4. Turn the Heater & Function switch knob on the stage 2 position to use TOP HEATING.
5. Turn the thermostat dial for the desired temperature.
6. When finished baking, turn the time dial till position “Off”, to switch off the oven.

HOW TO BROIL

1. Insert the removable wire rack with food and the all-purpose pan.
2. Turn the timer dial to the desired cooking time.
3. Keep the door half-open.
4. Turn the Heater & Function switch knob to the stage 3 position to use BOTTOM HEATING.
5. Turn the lower thermostat knob dial to the desired broiling time.
6. When finish broiling, turn the timer dial till position “Off” to switch off the oven.

HOW TO TOAST

1. Set the temperature control to 250C.
2. Turn the Heater & Function switch knob to the stage 4 position to use TOP & BOTTOM HEATING, turn on the lower and upper temperature knob to set the temperature at the same time.
3. Place food to be toasted on the wire rack.
4. Turn the Time Control to desired darkness. Bell will ring to signal the end of the Toast cycle.
5. When finish cooking, turn the timer dial till position “Off” to switch off the oven.

HOW TO USE THE CONVECTION FUNCTION

This convection function can be effected when you turn the “Heater & Function switch knob” to stage 5, which also have the “TOP & BOTTOM HEATING”,. Turn on the temperature knob to 250°C at the same time.

CLEANING

1. It is important that you clean the appliance after each use to prevent an accumulation of grease and avoid unpleasant odors.
2. Allow the appliance to cool and unplug from outlet before cleaning.
3. Do not immerse appliance in water or wash it under waterspout.
4. Removable wire rack, bake pan, crumb tray can be washed, as normal kitchenware.
5. Clean outside of appliance with a damp sponge.
6. Do not use abrasive cleaners or sharp utensils to clean the oven, as scratching may weaken it and cause shattering.
7. Let all parts and surfaces dry thoroughly prior to plugging oven in and using.

SAFETY NOTICE:

KEEP OUT OF CHILDREN REACH AND THERE IS ALWAYS ATTENDED BY AN ADULT WHILE OPERATING THE OVEN.

Sole Agent:

Libya

Mersin Inc.

Ali Bin Abi Taleb St.

Tripoli, Libya

P.O.Box: 84568

T. + 218 21 363 8016

info@hommerlibya.com

BVI

HOMMER CORPORATION

Wickhams Cay, Road Town

Tortola, B.V. Islands.

P.O.Box: 146.

T. +1 284 494 2434

info@MyHommer.com

٦. لا تستخدم المنظفات الكاشطة أو الأواني الحادة لتنظيف الفرن، لأن الخدش قد يضعفه ويسبب تهشمه.

٧. اترك جميع الأجزاء والأسطح تجف تماماً قبل توصيل الفرن واستخدامه.

إشعار الأمان:

يُحفظ بعيداً عن متناول الأطفال، حيث يحضر دائماً شخص بالغ أثناء تشغيل الفرن.

جزر العذراء البريطانية

هومر كوربوريشن

ويكهامز كاي، رود تاون، تورتولا،

جزر العذراء البريطانية،

ص. ب 146

+1 284 494 2434

info@MyHommer.com

الوكيل الحصري:

ليبيا

شركة مرسين المساهمة

شارع علي بن ابي طالب

طرابلس، ليبيا

ص. ب 84568

+ 218 21 363 8016

info@hommerlibya.com

www.myhommer.com

٥. أدر قرص منظم الحرارة لدرجة الحرارة المطلوبة.
٦. عند الانتهاء من الخبز، أدر قرص الوقت حتى الوضع «إيقاف التشغيل»، لإيقاف الفرن.

كيفية الشواء

١. أدخل رف الأسلاك القابل للإزالة مع الطعام والوعاء متعدد الأغراض.
٢. أدر قرص المؤقت إلى وقت الطهي المطلوب.
٣. اترك الباب نصف مفتوح.
٤. أدر مقبض مفتاح السخان والوظيفة إلى وضع المرحلة ٢ لاستخدام التسخين السفلي.
٥. أدر مفتاح مقبض منظم الحرارة السفلي إلى وقت الشوي المطلوب.
٦. عند الانتهاء من الشوي، أدر قرص المؤقت حتى وضع «إيقاف التشغيل» لإيقاف الفرن.

كيفية التحميص

١. اضبط مفتاح التحكم في درجة الحرارة على ٢٥٠ درجة مئوية.
٢. أدر مقبض مفتاح السخان والوظيفة إلى وضع المرحلة ٤ لاستخدام التسخين العلوي والسفلي، قم بتشغيل مقبض درجة الحرارة السفلي والعلوي لضبط درجة الحرارة في نفس الوقت.
٣. ضع الطعام المراد تحميصه على رف الأسلاك.
٤. أدر مفتاح التحكم في الوقت إلى درجة التحميص المطلوبة. سيرن الجرس لإشعارك بانتهاء دورة التحميص.
٥. عند الانتهاء من الطهي، أدر قرص المؤقت حتى وضع «إيقاف التشغيل» لإيقاف الفرن.

كيف يمكنك استعمال خاصية المروحة

يمكنك تشغيل خاصية المروحة عند تغيير مفتاح «التسخين و الخاصية» الي المستوى ٥ (وهي ايضا وضع التسخين من الاعلى و الاسفل). قم بلف مفتاح الحرارة الي ٢٥٠ درجة مئوية في نفس الوقت.

التنظيف

١. من المهم أن تنظف الجهاز بعد كل استخدام لمنع تراكم الشحوم وتجنب الروائح الكريهة.
٢. اترك الجهاز ليبرد وافصله عن مأخذ التيار قبل التنظيف.
٣. لا تغمر الجهاز في الماء أو تغسله تحت صنوبر الماء.
٤. رف الأسلاك القابل للإزالة، صينية الخبز، وصينية الفتات يمكن غسلها، كأدوات المطبخ العادية.
٥. نظف خارج الجهاز بإسفنج رطبة.

٢٠. لا تضع أي من المواد التالية في الفرن: كرتون، بلاستيك، ورق، أو ما شابه ذلك.
٢١. لا تقم بتخزين أي مواد في هذا الفرن عند التشغيل، بخلاف الملحقات الموصى بها.
٢٢. احرص دائماً على ارتداء قفازات الفرن الواقية المعزولة عند إدخال أو إخراج العناصر من الفرن الساخن.
٢٣. لا تستخدم الجهاز في الهواء الطلق.
٢٤. لا تستخدم الجهاز لغير الغرض المخصص له.

قبل استخدام فرن الطهي خاصتك

قبل استخدام هذا الفرن لأول مرة:

١. تأكد من أن الفرن غير موصول وأن مفتاح المؤقت في وضع «إيقاف التشغيل»
٢. قم بإزالة جميع الرفوف والمقالي وتنظيفها في الماء الساخن أو في غسالة الأطباق.
٣. جفف جميع الملحقات تماماً وأعد تجميعها في الفرن. قم بتوصيل الفرن بالمقبس وستكون جاهزاً لاستخدام فرنك الجديد.
٤. بعد إعادة تجميع الفرن الخاص بك، نوصي بتشغيله على درجة حرارة قصوى، وتشغيل جميع وظائف الفرن والألواح الساخنة لمدة ١٥ دقيقة تقريباً للتخلص من أي زيت تعبئة قد يتبقى بعد الشحن.

بالنسبة للفرن

لا داعي للقلق بشأن الدخان في التشغيل الأول، فهو طبيعي لأول تشغيل وسيختفي في غضون ٢٠ دقيقة. بشكل عام، ليس من الضروري تسخين الفرن مسبقاً، حيث تم تشغيل الوحدة التجريبية في خط الإنتاج. ولكن قد يكون من الأفضل لك تسخين الفرن قبل طهي بعض الوجبات الرقيقة، مثل اللحوم المتوسطة الكثافة والكعك.

كيفية الخبز:

١. ضع الرف القابل للإزالة في الموضع المطلوب.
٢. ضع صينية الخبز على رف الأسلاك؛ وأغلق باب الفرن.
٣. أدر قرص المؤقت إلى وقت الطهي المطلوب.
٤. أدر مقبض مفتاح السخان والوظيفة في موضع المرحلة ٢ لاستخدام التسخين العلوي.

إجراءات وقاية هامة

عند استخدام فرن الطهي هذا، يجب دائماً اتباع الاحتياطات الأساسية، بما في ذلك ما يلي:

١. اقرأ جميع التعليمات.
٢. تأكد من أن المقبس مؤرض جيداً قبل توصيل هذا الجهاز.
٣. لا تلمس الأسطح الساخنة للألواح الساخنة والفرن، استخدم الأيدي أو المقابض.
٤. الإشراف الدقيق ضروري عند استخدامه من قبل الأطفال أو بالقرب منهم.
٥. للحماية من الصدمات الكهربائية، لا تغمر السلك أو القابس أو أي جزء من أجزاء فرن الطهي في الماء أو أي سائل آخر.
٦. لا تدع السلك يتدلى على حافة الطاولة أو يلمس الأسطح الساخنة.
٧. لا تقم بتشغيل الأجهزة التي بها سلك أو قابس تالف أو بعد تعطل الجهاز أو تعرضه للتلف بأي شكل من الأشكال. أعدّه إلى أقرب مركز خدمة معتمد لفحصه أو إصلاحه أو تعديله.
٨. قد يؤدي استخدام الملحقات غير الموصى بها إلى حدوث خطر أو إصابة.
٩. لا تضع الجهاز على أو بالقرب من الغاز الساخن أو الموقد الكهربائي، أو في فرن ساخن أو في فرن الميكروويف.
١٠. عند تشغيل الفرن، احتفظ بمسافة لا تقل عن أربع بوصات على جميع جوانب الفرن للسماح بتدوير الهواء بشكل كافٍ.
١١. افصله من المأخذ عندما لا يكون قيد الاستعمال وقبل التنظيف. اتركه يبرد قبل تركيب الأجزاء أو خلعها، وقبل التنظيف.
١٢. للفصل، أدر مفتاح التحكم إلى وضع إيقاف التشغيل، ثم انزع القابس، وأمسك القابس دائماً، لكن لا تسحب السلك أبداً.
١٣. يجب توخي الحذر الشديد عند تحريك جهاز يحتوي على زيت ساخن أو سوائل ساخنة أخرى.
١٤. لا تغطي أي جزء من الفرن بورق معدني.
١٥. لا تقم بالتنظيف باستخدام وسادات الجلي المعدنية، فقد تنقطع الوسادة وتلامس الأجزاء الكهربائية، مما يؤدي إلى خطر حدوث صدمة كهربائية.
١٦. لا تترك الجهاز دون مراقبة أثناء الشوي أو التحميص.
١٧. يجب عدم إدخال الأطعمة كبيرة الحجم أو الأواني المعدنية في فرن التحميص لأنها قد تسبب نشوب حريق أو خطر حدوث صدمة كهربائية.
١٨. قد ينشب حريق في حالة تغطية الفرن أو ملامسته لمواد قابلة للاشتعال، بما في ذلك الستائر والجدران. وأحياناً أثناء التشغيل. لا تقم بتخزين أي عنصر على الفرن أثناء التشغيل.
١٩. يجب توخي الحذر الشديد عند استخدام الأوعية المصنوعة من أي شيء آخر غير المعدن أو الزجاج.

لوحة التحكم والتشغيل والتعليمات



إعدادات درجة الحرارة العلوية والسفلية:

تتراوح درجة الحرارة القابلة للتعديل من ١٠٠ درجة مئوية إلى ٢٥٠ درجة مئوية.

بعد أن تصل درجة حرارة الفرن إلى درجة محددة مسبقًا، يدخل منظم الحرارة تلقائيًا إلى الحالة

إعدادات الوظائف:

عنصر التسخين العلوي قيد التشغيل ☐

عنصر التسخين السفلي قيد التشغيل ☐

عناصر التسخين العلوية والسفلية قيد التشغيل ☐

الطهي خيارات كافة في تعمل مروحة ☒

المؤقت:

قابل للضبط من ٠ - ١٢٠ دقيقة

ملحوظة: النموذج مطبوع على لوحة التحكم الخاصة بالمنتج قد يتم تحديثه من دون سابق إشعار.

أسماء الأجزاء



ح



ز



ط

ب. مفتاح التحكم في درجة الحرارة السفلى

د. مفتاح التحكم في درجة الحرارة العليا

و. مقبض الباب

ح. صينية الخبز

ط. مقبض الصينية

أ. مفتاح التحكم في الوقت

ج. مفتاح التحكم في مصدر التسخين

هـ. جسم الجهاز

ي. باب زجاجي

ز. رف أسلاك

فرن كهربائي



عربي

دليل التعليمات

اقرأ واحفظ هذه التعليمات
انتبه: الصور الموجودة في هذا الدليل للرجوع إليها فقط.